



## PJ Bottoms Instructions

- 1) Pin 1 front and 1 back right sides together at inseam. Sew together in a 1.5 cm seam. Seam finish edges with the serger. Repeat for other leg.




- 2) Pin together the outer leg seams right side together. Sew together in a 1.5 cm seam. Seam finish edges with the serger. Repeat for other leg.




- 3) Turn one leg right side out. Put this leg inside of the other one, matching the inseams together by pinning. Pin the rest of the "u" shaped curve.

- 4) Starting at the top of the U curve, sew together in a 1.5 cm seam. Then sew a second row of stitching just on the inside of the 1.5 cm seam allowance for reinforcement. Seam finish edges with the serger. Press seams to the side.



- 5) Turn the shorts right side out. Topstitch neatly from the front of the shorts to the back of the shorts. When you do this you should be sewing the seam allowance to the shorts.



- 6) For the casing, press the top edge of the shorts towards the inside, 1 cm all the way around. Press again this time 4 cm and pin in place. Make sure your casing is pressed neatly and evenly. Sew close to the pressed edge, leaving a 3 cm opening to insert elastic.

- 7) Pull elastic through the casing, using a safety pin. Slightly overlap elastic and sew together with at least 3 rows of stitching. Sew the opening of the casing shut as neatly as possible.
- 8) To prevent the elastic from twisting, from the outside, stitch in the ditch for each seam along the casing.
- 9) Turn shorts, right side out. Press up each leg 1 cm all the way around. Then press each leg up 1.5 or 2.5cm and topstitch neatly on the pressed edge.

